

Усилитель серии У000 (артикул У003)



DETONATOR

Ламповый гитарный усилитель



Руководство
по эксплуатации

YERASOV®

1.	1
2.	2
3.	2
	3
	CLEAN CHANNEL	4
	BRIGHT CLEAN GAIN	4
	LEAD CHANNEL	5
	BRIGHT LEAD GAIN	5
	DAMPING	6
	PRESENCE MASTER	6
4.	7
	EFFECT LOOP	7
	8
	FOOTSWITCH	8
	SPEAKERS	9
	PENTOD –TRIODE	10
	FUSE	10
5.	10
	TUBE SELECT	10
6.	11
7.	12
8.	12
9.	13

1.

DETONATOR

:

10

:

:

2.

1. Footswitch

FS-33

2.

Bull 412

8

3.

4.

30

POWER

ON ()

“STANDBY”

5.

STANDBY
MASTER

ON (),

6.

STANDBY

ON ().

!

STANDBY

5-10

POWER

1.

(FS).

CLEAN

2.

SEND LEVEL

3. EFFECT LOOP

:


SERIAL- PARALLEL. EFFECT LOOP
 SERIAL,
 FOOTSWITCH.
 SEND LEVEL RETURN LEVEL
 RETURN LEVEL
 MASTER.

4.

SEND LEVEL

RETURN LEVEL
 SEND LEVEL.

3.



POWER. INPUT

GAIN –

DETONATOR,
 GAIN

VOLUME –

TREBLE –

GAIN.

(MIDDLE BASS),

MIDDLE –


MIDDLE

BASS –

TREBLE
BASS MID

TREBLE

CLEAN CHANNEL




DETONATOR

BRIGHT CLEAN GAIN

BRIGHT –

1
OFF.

2



GAIN

GAIN.
GAIN,
BRIGHT.

BRIGHT

CLEAN GAIN –
SINGLE HUMB

« » « »

– HUMB


HUMB
SINGLE
HI CLEAN

DETONATOR

CLEAN CHANNEL

GAIN MIDDLE

LEAD CHANNEL



LEAD CHANNEL –



CLEAN(FS)

LEAD

LEAD CHANNEL

LO LEAD HI LEAD,

LO
HI LEAD –

BRIGHT LEAD GAIN

BRIGHT –




1. 2.
BRIGHT CLEAN CHANNEL.
: OFF, 1 2.
BRIGHT LEAD CHANNEL
BRIGHT (OFF)

LEAD GAIN – : VINTAGE, BOOST VINTAGE MODERN.

VINTAGE « »- LO LEAD

BOOST VINTAGE –
MODERN

DETONATOR



DAMPING

OFF DAMPING **DETONATOR** ON

PRESENCE MASTER

PRESENCE

PRESENCE


PRESENCE “ ”

MASTER

POWER


STANDBY.

4.



EFFECT LOOP

EFFECT LOOP.



1.
DETONATOR

(SERIAL)
(PARALLEL)

SERIAL/PARALLEL.


2. SEND LEVEL
DETONATOR
3. SEND
4. RETURN
5. RETURN LEVEL SERIAL

SEND RETURN. / EFFECT LOOP

(RETURN LEVEL),
5 dB,
4 dB.

1. SEND.
2. RETURN.
3. SEND LEVEL
4. RETURN LEVEL.
5. SERIAL-PARALLEL.
 SEND LEVEL RETURN LEVEL
 RETURN LEVEL (SERIAL)
 MASTER.
 RETURN LEVEL (PARALLEL)
 RETURN LEVEL


FOOTSWITCH



FS-33. CHANNEL
 CLEAN CHANNEL
 LEAD CHANNEL
 LEAD
 HIGH LOW.
 LEAD CHANNEL
 HIGH LEAD

LOOP.


FS-33,
 CLEAN (FS).



SPEAKERS

DETONATOR

4 , 8 16 .



SPEAKERS

(4 TUBES)

(2 TUBES)

! 4TUBES/2TUBES

(.).

4 TUBES

4 (

8 (

8),

16)

16 .

2 TUBES

8 (


16)

16 .

BULL 412

8 .

PENTODE – TRIODE



PENTODE
 TRIODE – , « ».

DETONATOR

1. 100W – 4 TUBES PENTODE;
2. 50W – 4 TUBES TRIODE;
3. 50W – 2 TUBES PENTODE;
4. 25W – 2 TUBES TRIODE.

!
 ()

STANDBY.

FUSE



(. . 2 – 4).

5.

TUBE SELECT

TUBE SELECT,



(6L6 EL34).
 6L6

EL34 (),

distortion

TUBE SELECT

6.

ECC83

ECC83

EL34 (6L6)

c

7.

		1
		4TUBES:	
TRIODE, ,		50
PENTODE, ,		100
		2TUBES:	
TRIODE, ,		25
PENTODE, ,		50
	50 ,	220±22
		300
		650 225 250
(,) ,		18
		5xECC83, 1x12AX7WA, 4xEL34(6L6)

8.

		DETONATOR,	1
	FS-33,		1
		T 3,15 A,	1
			1
		1 ,	1
			1
			1

9.

12

!

*

1

DETONATOR

60065, 22505,
51515, 51317.3.2-2006
(. . 6,7), 51317.3.3,
RU. 02. 05122

YERASOV MUSIC CORPORATION
440003,
/ . (8412) 93-03-56, 93-03-60.
E-mail: sale@yerasov.ru

20.

(_____)

DETONATOR

YERASOV MUSIC CORPORATION
440003, / . (8412) 93-03-56, 93-03-60. 20.
WWW.YERASOV.RU

(_____)

YERASOV MUSIC CORPORATION
www.yerasov.ru e-mail: sale@yerasov.ru